

FIG.21

TAG(DTAG)	MEANING
0001	FW-SOP
0010	FW-HDR
0011	FW-FTR
0100	FW-ORB
0101	FW-STRM
1001	HW-SOP
1010	HW-HDR
1011	HW-FTR
1100	HW-ORB
1101	HW-STRM

FW ..... FIRMWARE  
HW ..... HARDWARE  
SOP ..... START OF PACKET  
(INITIAL QUADLET OF RECEIVED PACKET)  
HDR ..... HEADER OTHER THAN SOP  
FTR ..... STATUS INFORMATION FOR THE TRANSMITTED PACKET  
ORB ..... ORB (DATA)  
STRM ..... STREAM (DATA)

